

Coaches and teams

Advanced configuration for coaches and teams



Start



HISTART

Starting gate



HILINK

10mW or 500mW radio transmission system



Athlete



HISMAART

Recognition system

Optional



Finish



HISENS

Professional radio-controlled photocell



RTPRO

Chronometer in Training Light mode



Coaches, Athletes, Guests...



HITIMING

View timed trials

Free

In detail

//////////

The Microgate ski training kit is designed for coaches and teams who need a comprehensive, portable and reliable timing system, even in challenging conditions or when multiple teams are on the same run. Packed into a handy rucksack, it includes a HiStart gate, HiLink radio, HiSens Radio photocell and RTPro chronometer to manage and print results directly on the slopes.

The system allows you to record times, split times and speeds, compare the performance of each athlete's runs, and manage useful data such as reference times, gate passes and notes on the equipment used. With the HiTiming app, you can import athletes' names from Excel, share results live and export rankings to PDF or Excel.

The setup can be expanded with additional HiSens Radio photocells for split times and speed sections, easy-to-install flexible poles and HiSmart devices for automatic athlete identification. The RTPro chronometer can also be used via cable for official competitions or other sports, with the option to connect to MicroTAB or MicroGraph display boards.

