

Timekeepers

Full configuration for timekeepers



Start



HISTART

Starting gate



INTERCOM

Intercom with headphones for communication



HILINK

HiLink for manual timekeeping



Intermediate



HISENS

Optional

Professional photocell (single/double)



Finish



HISENS

Professional photocell (single/double)



REIPRO

Chronometer in Training Light mode



MICROTABLED

LED display connected to the chronometer



INTERCOM

Intercom with headphones for communication



HILINK

HiLink for manual timekeeping



Apps and Data



HITIMING

Free

Managing and sharing timed trials

In detail



The Microgate ski timing system is designed for timekeepers who require a precise, robust and comprehensive FIS-approved solution for managing official races. The configuration includes a HiStart gate, HiLink Timer, HiSens photocell with reflector, a ReiPro chronometer synchronisable via GPS, and cable connections for the start, up to two intermediate points and the finish, expandable via LinkPod.

The dedicated alpine skiing software allows you to manage multiple athletes on the course simultaneously, including multiple runs, those who did not start, those who did not finish, those who were disqualified, and the start order for the second run using the BIBO rule. It also enables the printing of results lists and documents useful for judges and FIS Timing Reports, with results exportable to PDF and Excel for further processing.

Communication between the start and finish takes place on the same timing line via amplifiers with headphones, simplifying installation and reducing the need for separate systems. The system can be expanded to meet FIS requirements, up to the full management of Level 0 competitions. The ReiPRO chronometer can also be used for parallel events, ski cross, slalom courses and other sports such as mountain biking or running, whilst the RTPro chronometer can be integrated for simple competitions, as a backup or for manual timing.

